



RGE Tech Tips from the Field – Client Edition

Topic: Easy Mode Simplified for You

Chip's Weekly Cheat Sheet: Jul-27 🇺🇸

Topic: Samsung "Easy Mode": Simplified for You

1. Make Everything Bigger

- Samsung phones have a "secret" setting called **Easy Mode**. It instantly makes all your icons and text much larger and clears the "clutter" off your screen.
- **Chip's Tip: You can turn this on in Settings > Display > Easy Mode. It's like putting "Large Print" on your whole phone!**

2. Stop the "Accidental Tap."

- Easy Mode increases the time you have to hold an icon before it moves. This prevents you from accidentally deleting apps or moving things around when you're just trying to scroll.
- **Chip's Tip: This is the #1 way to stop your phone from "doing things on its own" while you're holding it.**

3. The High-Contrast Keyboard

- When Easy Mode is on, your keyboard changes to bright yellow keys with bold black letters. It is significantly easier to see than the standard grey keyboard.
- **Chip's Tip: This works wonders for anyone who finds themselves squinting at the screen while trying to send a text.**